

# MILTON



#SmartLife

 SMARTTIFFIN



 SMARTHOTPOT



# A device for a smarter lifestyle.

- Warm your meal wirelessly from anywhere (no minimum radius/distance from the tiffin required).
- Heat your tiffin or Hotpot via Milton Smart Devices app on your mobile or assistant speakers (Alexa & Google Assistant)
- Easy to connect. Quick and secure to use.
- Schedule your tiffin or Hotpot to enjoy a hot meal at your convenience.
- Welcome home mode allows you to turn on the heating of the tiffin while you are a certain distance away from the location, so that the food is hot and ready on your arrival.



Download Milton Smart Devices app.




# Index




- Specifications
- Safety
- Cleaning and maintenance
- Components
- Setting Up
- Status Indicator
- Getting Connected
- Demo
- FAQs 22 & Troubleshooting


# Specifications



**SMARTTIFFIN**  
1000 ml (80 W)



**SMARTHOTPOT PLUS**  
2500 ml (85 W)



**SMARTHOTPOT**  
1500 ml (50 W)

- Voltage 220-240V Frequency 50/60Hz
- Connectivity Wireless 802.11b/g WPA/WPA2

# Safety


Kindly read and adhere to the following notices and cautions before using the Smart Device:

- Before using the Smart Tiffin / Hotpot please check whether the voltage you adopt complies with the rated voltage of the product.
- Do not share the power socket with other electric appliances to avoid over-current.
- If the power cord is damaged please get it replaced at the earliest
- Do not expose to fire, heat, rain or sun.
- Do not immerse the device into water, as it will damage its components.
- After cleaning the appliance please ensure that the device and power supply plug is dry before the next use.
- The device is made only to warm food, do not use it for cooking.


# Cleaning and Maintenance

- Before cleaning the device, please ensure that the power has been unplugged.
- Any dirt on the surface of the device can be wiped off by damp cloth or rinsed under mild running water.
- Do not immerse the device into water or into any cleaning agent.
- The heating enclosure is not dishwasher safe. It has to be cleaned with hands only.
- The inner steel containers and its lids are dishwasher safe.

# Components










# Directions for use

 SMARTTIFFIN



- Our patented lid design ensures the food is secure in the container and doesn't spill and mix in other container's food contents.
- To open the heated food containers, the Air Lock needs to be carefully opened first, followed by which the lid can be easily slid out.

# Cleaning instructions



- To wash the lid, pull out the air vent using the elongated tip on the top (use of nails to be avoided as they may puncture the air vent)
- After washing, the tip has to be inserted at the bottom and then pulled from below.

# Setting Up



## FOR FIRST TIME USE:

Before using the device for the first time, ensure the container is clean and remove the packaging elements from inside as well as outside of the product.

## MANUAL USAGE:

When first connecting the device to the power supply, the Wi-Fi indicator will blink to show that the device is searching for a Wi-Fi connection. Once the device is connected, touch the Power button to start heating.

# Status Indicator



Wi-Fi Indicator :

Slow Blinking 2 times per second :

Searching for Network

Fast Blinking 4 times per second :

Connected to Internet

Configuration mode :

Fast Flickering 16 times per second

Power Indicator :

Heating ON/OFF



APP *to*  
**HEAT**



# Getting Connected



Milton app

Available on




1. Plug the device to the power supply.
2. Download the Smart Milton app from your app store.
3. Open the App and follow the step-by-step instructions to complete the setup.


## IMPORTANT

Please make sure that your smartphone is in range of the device network as well as your home network.







- Scan the QR code.  
(Placed on the inside of the lid)




- Register yourself by filling in the required details and accepting the user agreement.




- OTP will be received via SMS & Email



- Go to Configure Device.




- Rename your device to a friendly name.



- Make sure you are connected to the Wi-Fi network on your smart phone.
- Confirm the Wi-Fi network, enter the password and click save or type your SSID/Wi-Fi name, password and save




- Press the power button of the Tiffin/Hotpot for 5 seconds; Wi-Fi indicator will start flickering indicating the product is now into configuration mode.



Got to Wi-Fi settings

- Connect the phone to the device warmer from your phone's Wi-Fi settings and click next in the app. A message should appear saying "Success!"








Let your *voice assistants*



do the heating for you!

# Configuring ALEXA



(Device needs to be configured via Milton App prior to this)


- Click on Amazon Alexa and login using Amazon Password

*Note: Install Alexa app if required.*



- Enable "Milton" and link account

- Milton app credentials
- Give required setting details and allow access.
- Milton skill should be ready for use.


# ALEXA Smart Home



- Click "Smart Milton" and link account (Device needs to be configured via Milton App prior to this)




- Click on "Discover Devices"> Select setup device > Select Group > Done.




- Smart Home skill should be ready for use.

# Configuring Google



(Device needs to be configured via Milton App prior to this)

- Install Google Home app on your Smart Phone.
- Go to HOME > Select 'Add and Setup device'




- Click on "Works with Google TAB "




- Search for 'Milton' and select the one result that appears - 'Milton'




# Google Home / Assistant



- Login with your Milton Account and provide all permissions.



- On successful authentication your Milton account will be linked to your Google Home account.



- Google skill should be ready for use.

00:30



# Geotagging



HOME




1km left



OFFICE


# Welcome home mode



This Feature enables you to switch on your device automatically when you enter or leave a specific area between the set time.

(Enable Location services for this feature to work)

(Radius to be set manually depending on the distance from home/office)



E.g.

If you leave office everyday between 7 pm to 10 pm and it takes 40 minutes to reach home

Select Leave > Select your office Location with a range of 1 KM minimum> Set time range between 7 to 10 pm.> Click Set.

The Device will automatically start heating every day when you leave the office area thus welcoming you home to a hot meal..

# Frequently asked questions



If you can't find the answers you are looking for, then give us a call at our help line no. **1800 209 2151** or write to us at [info@hamiltonindia.in](mailto:info@hamiltonindia.in)

## **My device cannot connect to the network.**

To begin with, ensure your base is in the same room as your router. Launch the app, follow the instructions and enter in your network username and password. Please be aware that the username and password are case sensitive. It usually takes 5 minutes to get connected. While setting up the device, make sure the Wi-Fi signal is strong and details have been entered correctly.

**Please note:** The device works on a 2.4ghz frequency so kindly ensure that you are on the correct frequency by checking your router settings. If unsure, please contact your network provider for further instructions.

## **My device can't find the 'Milton warmer' while setting up the Smart Devices app.**

Turn the warmer off via the plug to reset and then search for the network. Go to your Wi-Fi settings and turn your Wi-Fi off/on for a few seconds (this may need to be done a few times).

**Please note:** This product is not calibrated for commercial or scientific use.

# Warranty Card

Model Description: .....

Date of Purchase: ..... Bill No: .....

Dealer Details : .....

.....

.....

I agree to the attached warranty conditions and I have noted the information contained in the use and care manual enclosed with this appliance. I further agree that I will not have any claim against the company in case of misuse, usage of spurious spares, and /or after the expiry of warranty period as specified in the warranty conditions.

Name of the Customer: .....

Address: .....

.....

Signature of customer



SMART IS



BEAUTIFUL



## DELHI

7-J, Gopala Tower, 25,  
Rajendra Place, Delhi - 110 008.  
Tel no : (011) 2586 2922 / 3130 2526.  
Email: [anum@hamiltonindia.in](mailto:anum@hamiltonindia.in)

## HYDERABAD

Linga Reddy Gardens, D. No:10-1, Beside Bharath Petrol Pump,  
Ramanthapur, Hyderabad - 500013  
Tel no: (040) 27037008  
Email: [hyderabad@hamiltonindia.in](mailto:hyderabad@hamiltonindia.in)

## KOLKATA

4, Chowringhee Lane, Block III / IV, Unit - 8,  
8th Floor, Diamond Chamber, Kolkata - 700 016,  
Tel no : (033) 2252 1852.  
Email: [calcutta@hamiltonindia.in](mailto:calcutta@hamiltonindia.in)

**Hamilton**  
**Housewares P. Ltd.**

2nd Floor, One Forbes, Dr. V. B. Gandhi Marg,  
Fort, Mumbai - 400 001, India.  
Tel: (022) 61280505.

[info@hamiltonindia.in](mailto:info@hamiltonindia.in)  
[www.hamiltonindia.in](http://www.hamiltonindia.in)

[f/milton.in](#) [v/milton](#) [t/miltonhomewares](#) [i/milton\\_homewares](#)



[www.milton.in](http://www.milton.in)